



ATCOM Multicast paging user manual

Version: 1.0

2017-09-4

Contact ATCOM

Overview of ATCOM

ATCOM is the leading VoIP hardware manufacturer in global market. We have been keeping innovating with customer's needs oriented , working with partners to establish a total solution for SMB VoIP with IP phone , IP PBX and Asterisk cards

With over 10 years' experience of R&D , manufacturing and service in network and VoIP filed ; mission of creating the biggest value for IP terminals , we commit ourselves in supplying the competitive IP phone and other terminals for IP PBX , soft switch , IMS , NGN providers and carriers; supplying the competitive total VoIP solution for SMB market. We keep improving the customer's experience and creating the bigger value with our reliable products. Until now, our VoIP products have been available in 100+ countries and used by millions of end users.

Contact Sales

Address	Area C, A2F , Block 3 ,Huangguan Technology Park , #21 Tairan 9th Rd, Chegongmiao , Futian District , Shenzhen China
Tel	+ (86) 755-83018618-8806
Fax	+ (86) 755-83018319
E-mail	sales@atcom.com.cn

Contact Technical Support

Tel	+ (86) 755-83018618-8003
E-mail	Support@atcom.com.cn

Website Address: <http://www.atcom.cn/>

Download Center: <http://www.atcom.cn/download.html>

Content

Contact ATCOM.....	2
Overview of ATCOM	2
1 .Overview.....	4
2 .Configuration.....	4
2.1. Configure the Paging list.....	4
2.2. Configure the multicast Paging send key.....	5
2.3. Configure the listening Paging.....	6

1 .Overview

Multicast Paging allows you to send pages to groups of phones directly, without the PBX being involved in the page. With multicast paging, phones are programmed to listen to a broadcast address. The advantage to this method is that the multicast page is a single SIP call instead of a multiple-party conference call. This greatly reduces the workload placed on the PBX, especially when a large number of devices are involved.

All phones that you want to include in the multicast paging group need to be on the same network, since a network broadcast protocol is used.

2 .Configuration

Multicast paging allows IP phones to send/receive Real-time Transport Protocol (RTP) streams to/from the pre-configures multicast address on the desired channel without involving SIP signaling.

The valid multicast IP address range from 224.0.0.0 to 239.255.255.255, the valid port number is 0 to 65535, and the channel is 0 to 30.

The multicast IP address and port enter together.

For example: 238.238.238.0:10001 .

Note: the multicast paging just support one-way talk, the paging list way send voice, and the listening address ways only can receive voice.

2.1. Configure the Paging list

User can send an RTP stream without involving sip signaling by pressing a configured multicast Paging key or a paging list key.

When the phone sends the RTP stream to a pre-configured multicast address belongs to a desired channel, each phone preconfigured to listen to the multicast address on the same channel can receive the RTP stream.

To configure the sending paging list address via webpage:

1. Please go to 'Contacts -> Multicast IP -> Paging list'.
2. Enter the IP address and port in the Paging Address field.
3. Enter the label in the Label field, the label would appear on the LCD screen.

atcom		Basic	Account	Network	DSS Keys	Phone	Contacts	
Contacts	30 IP Address	<input type="text"/>	<input type="text"/>	0	▼	30		
	31 IP Address	<input type="text"/>	<input type="text"/>	0	▼	31		
Remote Phonebook	Paging List							
LDAP	Index	Paging Address	Label			Channel		
Multicast IP	1	<input type="text" value="224.100.100.100:10001"/>	<input type="text" value="test1"/>			0	▼	
	2	<input type="text" value="224.100.100.101:10002"/>	<input type="text" value="test2"/>			0	▼	
	3	<input type="text"/>	<input type="text"/>			0	▼	
	4	<input type="text"/>	<input type="text"/>			0	▼	
	5	<input type="text"/>	<input type="text"/>			0	▼	
Phone Call Info								

2.2. Configure the multicast Paging send key

To configure the multicast paging list send key :

1. Please access to the webpage and go to 'DSS keys -> Memory keys (other programmable keys)'.
2. In the desired DSS key field, select paging or paging list from the type.
 Paging: when select the paging, it need enter the paging address and port completely.
 Paging list: when select the paging list, you can choose the address from the list.

English Logout

atcom		Basic	Account	Network	DSS Keys	Phone	Contacts
Memory Keys	Key	Type	Value	Label	Account	Extension	
	DSS Key1	Paging	224.100.100.100:10001	test1	Auto		
	DSS Key2	N/A			Account 1		
	DSS Key3	Line			Account 1		
	DSS Key4	Speed Dial			Account 1		
DSS Key5	BLF			Account 1			
DSS Key6	Direct Pickup			Account 1			
DSS Key7	Group Pickup			Account 1			
DSS Key8	Call Park			Account 1			
DSS Key9	Intercom			Account 1			
DSS Key10	DTMF			Account 1			
DSS Key11	Conference			Account 1			
DSS Key12	HOLD			Account 1			
	Do Not Disturb (DND)			Account 1			
	Redial			Account 1			
	Directory			Account 1			
	Call Return			Account 1			
	Prefix			Account 1			
	LDAP			Account 1			
	Paging			Account 1			
	Paging List			Account 1			

Memory Keys	Key	Type	Value	Label	Account	Extension
Line Keys	DSS Key1	Paging	224.100.100.100:1000	余蕾	Auto	
Programmable Keys	DSS Key2	Paging List			Auto	
EXT Keys	DSS Key3	N/A			Account 1	
	DSS Key4	Line			Account 1	
	DSS Key5	Speed Dial			Account 1	
	DSS Key6	BLF			Account 1	
	DSS Key7	Direct Pickup			Account 1	
	DSS Key8	Group Pickup			Account 1	
	DSS Key9	Call Park			Account 1	
	DSS Key10	Intercom			Account 1	
	DSS Key11	DTMF			Account 1	
	DSS Key12	Conference			Account 1	
	DSS Key13	HOLD			Account 1	
		Do Not Disturb (DND)			Account 1	
		Redial			Account 1	
		Directory			Account 1	
		Call Return			Account 1	
		Prefix			Account 1	
		LDAP			Account 1	
		Paging			Account 1	
		Paging List			Account 1	

3. Press the configured button in the phone, it will sending the multicast paging address.

2.3. Configure the listening Paging

IP phones can receive an RTP stream from the pre-configured multicast address without involving SIP signaling, and can handle the incoming multicast paging calls differently depending on the configurations of Paging Barge and Paging Priority Active.

Paging Barge:

The parameter defined the priority of the voice call in progress.

Disable the Paging Barge feature, if the phone is making a sip call, it will not listen the multicast paging address.

Configure the priority is 4, it will receive the priority 1,2,3,4 multicast paging calls.

Ignore DND:

The parameter is means cannot be received the multicast call when DND is activated.

Configure the priority is 4, it will receive the priority 1,2,3,4 multicast paging calls.

Paging Priority Active:

Disable the feature, the phone can receive any one multicast paging call.

Enable the feature, an incoming multicast paging call with higher priority is automatically answered, and the one with low priority is ignored.

To configure the multicast listening addressed via webpage:

1. Please go to 'Contacts -> Multicast IP -> Multicast Listening'.
2. Enter the IP address and port which the phone listens to for incoming RTP multicast in the Listening Address field.
3. Enter the label in the Label field, the label would appear on the LCD screen.

IP Address	Listening Address	Label	Channel	Priority
1 IP Address	224.100.100.100:10001	yulei1	0	1
2 IP Address	224.100.100.101:10002	yulei2	0	2
3 IP Address			0	3